

CL63220

US-Diesel F7A / F7B

Sound	Bezeichnung	F-Taste
1	Crossing	1
2	Bremse anlegen	2
3	Glocke	3
4	Ansage	4
5	Bremse lösen	10
6	Luft ablassen	12
7	Horn	5
8	Blow Down	9
9	Alarmglocke	11
10	Signalhorn tief	7
11	Anfahrtsignal vorwärts	--
12	Anfahrtsignal rückwärts	--

	Sound aus / an	8
	Lok aufrüsten aus / an	6

Eine Doppelbelegung der F-Tasten ist nicht möglich. Es wird der erste Sound mit der entsprechend zugeordneten F-Taste ausgelöst.

Weitere Informationen zu unseren Produkten finden Sie auch im Internet unter: www.champdex-linden.de
LGB ist ein eingetragenes Warenzeichen der Gebr. Märklin & Cie. GmbH, Göppingen.

CL63220

US-Diesel Loco F7A / F7B

Sound	Description	F-Key
1	Crossing	1
2	Brake	2
3	Bell	3
4	Speech	4
5	Release Brakes	10
6	Release Air	12
7	Horn	5
8	Blow Down	9
9	Alarm Bell	11
10	Signalhorn low	7
11	Train Starting Signal forward	--
12	Train Starting Signal Backward	--

	Sound off / on	8
	Starting Loco off / on	6

A duplicate assignment of Function-Keys is not possible. The first sound addressed to the according F-key will be played.

Additional information about our products can be found on our website www.champdex-linden.de
LGB is a registered trademark of Gebr. Märklin & Cie. GmbH, Göppingen.