

CL63420 Strassenbahn

Sound	Bezeichnung	F-Taste
--	--	--
1	Glocke aussen	1
2	Bremsgeräusch	2
3	Warnglocke	3
4	Ansage „Nächster Halt Bahnhof“	4
5	Schalthebel	5
6	Tür zu	0
7	Kurvenquietschen	7
8	Bimmel innen	9
9	Ansage „Linie 1 endet hier. Bitte alles aussteigen“	10
10	Ansage „Die Fahrausweise Bitte“	11
11	Schienenstoss	12
12	Anfahrtsignal	--

	Sound aus / an	8
	Lok aufrüsten an / aus	6

Eine Doppelbelegung der F-Tasten ist nicht möglich. Es wird der erste Sound mit der entsprechend zugeordneten F-Taste ausgelöst.

Weitere Informationen zu unseren Produkten finden Sie auch im Internet unter: www.champdex-linden.de
LGB ist ein eingetragenes Warenzeichen der Gebr. Märklin & Cie. GmbH, Göppingen.

CL63420 Streetcar

Sound	Description	F-Key
--	--	--
1	Bell outside	1
2	Braking sound	2
3	Warning bell	3
4	Announcem. „Next stop, depot“ (German)	4
5	Gearshift	5
6	Closing doors	0
7	Squeak on curve	7
8	Small bell inside	9
9	Announcem. „Route 1 ends here, please step off“ (German)	10
10	Announcem. „Tickets please“ (German)	11
11	Rail joint	12
12	Starting signal	--

	Sound off / on	8
	Loco start up on / off	6

A duplicate assignment of Function-Keys is not possible. The first sound addressed to the according F-key will be played.

Additional information about our products can be found on our website www.champdex-linden.de
LGB is a registered trademark of Gebr. Märklin & Cie. GmbH, Göppingen.